

DASHFLASH INSTRUCTIONS

To select the various functions available through the dash, press mode repeatedly until the desired function is visible: (depending on year and configuration these may not be in the correct order and some may not be available)

- Lap Time
- Ski Mode
- Fuel Consumption
- VTS Mode
- Display
- Fault Codes
- Key Mode
- Settings

Press up or down buttons to scroll through the menu. Press set button to enter that function.

See your year specific manual for normal OEM functions. We will only cover added DashFlash functions in this instruction set.

Navigate to the Display function and press Set button. (See above)

Press up or down buttons to navigate this subfunction menu: (depending on year and configuration these may not be in the correct order and some may not be available)

- Depth (if you ski has Depth)
- RPM
- AFR
- Boost
- IAT (Intake Air Temperature)
- Voltage
- Throttle % (Percentage of Throttle body opening)
- Estimated Horsepower
- Speed
- Engine Temp
- Top Speed
- Avg Speed
- Top RPM
- Avg RPM
- Clock

Press up or down buttons to scroll through the menu. Press set button to set and save that preferred indication. This will display in the top numeric area of the LCD.

Navigate to the Settings Function and press set button. (See above)

(depending on year and configuration these may not be in the correct order and some may not be available)

- Middle Screen Selection
- Lake Temp Selection
- Speed Override Selection
- Display Units
- Clock

Press up or down buttons to scroll through the menu. Press set button to enter the desired function.

Middle Screen Selection subfunction menu:

- Compass
- Depth
- RPM
- Speed
- AFR
- Boost
- IAT (Intake Air Temperature)
- Voltage
- Throttle
- Engine Temp
- Estimated Horsepower
- No Display

Press up or down buttons to scroll through the menu. Press set button to set and save that preferred indication. This will display in the middle numeric area of the LCD in the OEM compass location. (Note on some versions of DashFlash this area is only visible while the ski is underway just like the OEM compass.)

Lake Temperature Selection subfunction menu:

- Lake Temp
- Depth
- IAT (Intake Air Temperature)

Press up or down buttons to scroll through the menu. Press set button to set and save that preferred indication. This will display in the lower left corner next to the hour meter.

Speed Override Selection subfunction menu:

- Speed override Off
- Speed override On

Press up or down buttons to scroll through the menu. Press set button to set and save that preferred setting. This is typically used on none reflashed ECU skis. It removes the OEM speed limiter feature. Most ECU reflash include this feature and is not needed on DashFlash. If you use a Datalogger and are having issues logging speed above 68 MPH turn this setting off to log accurate speed.

© Dashpac.com 2020