

# ULTIMATE DASHPAC INSTRUCTIONS

## DASHFLASH FLASH INSTRUCTIONS


1) The Module and sensor need to be installed just like Original DashPac. See instructions here;

<https://www.dashpac.com/2010-bosch-ecu.html>

2) Grab your favorite Wi-Fi capable smart device. Enable Wi-Fi and power up the Ski.

3) Browse available signals and look for one named DashPac. Connect.

4) Once connected browse to [www.dashpac.com](http://www.dashpac.com)



5) From here navigate to the Setup/DashFlash tab.



- 1) If you purchased a DashFlash Credit when you Bought the Ultimate DashPac you will See a DashFlash Utility Button.
- 2) To start the process of DashFlashing click the button.

# TERMS

For warranty service, please email at [andy@dashpac.net](mailto:andy@dashpac.net) . When requesting warranty service, you must present the original dated sales receipt.


If Dash Reflashing fails or has any issues the user agrees to pull the dash from the ski and ship back to DashPac for Software Repair's at the users expense.

DashPac agrees to repair or at DashPac's option, replace any defective unit without charge, if product is returned to DashPac Freight prepaid within the warranty period. Any equipment returned which, in DashPac's opinion, has been subjected to misuse, abuse, overheating or accident shall not be covered by this warranty.

DashPac shall have no liability for special, incidental or consequential damages or injury to persons or property from any cause arising from the sale, installation or use of this product.

No other warranty, express or implied, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose, applies. Various states do not allow for the limitation of incidental or consequential damages and therefore the above exclusion or limitation may not apply to you.

Warranty does not include the expenses related to freight or transportation of parts or compensation for any inconvenience or loss of use while being repaired. A copy of the original invoice and a Return Authorization Number (RA#) must accompany all warranty claims. Warranted replacement parts will be returned freight collect.




If you have read, understand, and agree to the terms listed above click the button.



Here you will see more information on what to do.

If your DashFlashing this is what you will see. If you already DashFlashed the button will say Flash the Dash to Stock. Flashing typically takes 3 min but can take up to 5 min. Make sure you have a good fully charged battery before continuing. Its not a bad idea to pull the key fully off the post and quickly reinstalling it before pushing the Button. Once you push the button don't do anything to the smart device or ski until its complete. You should see the following screen shots as its flashing.



Once you see the Dash Reset click The Dash Reset Button to exit the Flash Utility. And you're done!